

Service Bulletin

Mazda Motor of America, Inc.
7755 Irvine Center Drive
Irvine, California 92718
Telephone (714) 727-1990




Category 7	Applicable Model/s All MTX Models	Subject PROPER INSTALLATION OF CHANGE ROD BOOT	Bulletin No. 056/89 Issued 2/15/89 Revised
---------------	--------------------------------------	--	--

DESCRIPTION

When you remove the change rod boot for repair, be sure to install it with the air breather hole directed downward.

This is to prevent water or mud from collecting inside the boot through the air breather hole. If water or mud does come into the boot area, it will cause corrosion on the change rod and as a result, the oil seal will be damaged, which may cause oil leakage.



IMPORTANT Service and Parts Managers should read this bulletin carefully, sign and convey all information to those concerned

Signature _____

Service Manager

Signature _____

Parts Manager

014395